


Assembly Instruction CONSOLE TABLE



Carefully unpack and identify each component before beginning assembly. Before you begin, please refer to parts list to make sure that you have all parts. Please take care when assembling the unit and always place the parts on a clean, soft surface.

Get social with us and discover more about our products, tips and exclusive discounts!















PRE-ASSEMBLY PREPARATION

CAUTION: Assembly will require at least 2 adults. DO NOT use power tools. Please inspect all items BEFORE assembly. If for any reason you need to return this item, please kindly return it in it's original packaging.

WARNING!

- 1. DO NOT let any sharp objects touch or rub the surface of the product.
- 2. When assembling, do not let children play around the working area.
- 3. DO NOT tighten all bolts and screws completely until the entire unit has been assembled and set up.
- 4. DO NOT USE if this product become damaged, and/or components are broken or missing.
- CARE AND CLEANING: DO NOT scratch or chip the finish. DO NOT use abrasive chemicals for cleaning. Clean with mild soap on a soft rag. Rinse and dry thoroughly.
- **MAINTENANCE:** Please periodically check all fittings and re-tighten as necessary.

Explosive View






PARTS LIST			
BACK X STEEL BAR (A)	BACK TOP CROSS BAR (B)	FRONT TOP CROSS BAR (C)	FRONT BOTTOM CROSS BAR (D)
		*	
Qty: 2	Qty: 1	Qty: 1	Qty: 1
BACK BOTTOM CROSS BAR (E)	TOP PANEL (F)	BOTTOM PANEL (G)	LEG FRAME (H)
Qty: 1	Qty: 1	Qty: 1	₩ Qty: 2
HARDWARE LIST			
ALLEN BOLTS (1)	PHILLIPS SCREW (2)	PHILLIPS SCREW (3)	ALLEN WRENCH (4)
M6*12mm	5*12mm	4*15mm	4mm
Qty: 8	Qty: 12	Qty: 3	Qty: 1
NOT INCLUDED			

glitzhome®

REQUIRED HARDWARE IN THIS STEP			
NO.	DESCRIPTION	SKETCH	QTY
1	ALLEN BOLT M6*12mm		4PCS
4	ALLEN WRENCH		1PC

STEP 1


Assemble front top cross bar (C) and back top cross bar (B) on leg frame (H) with Allen bolts (1) by using Allen wrench (4). Please don't tighten all screws until process step 2!



REQUIRED HARDWARE IN THIS STEP			
NO.	DESCRIPTION	SKETCH	QTY
1	ALLEN BOLT M6*12mm	9	4PCS
4	ALLEN WRENCH		1PC

STEP 2

Assemble front bottom cross bar (D) and back bottom cross bar (E) on leg frame (H) with Allen bolts (1) by using Allen wrench (4).






REQUIRED HARDWARE IN THIS STEP			
NO.	DESCRIPTION	SKETCH	QTY
3	PHILLIP SCREW 4*15mm	4	3PCS
	PHILLIPS SCREW DRIVER		Not included

STEP 3


Assemble back X steel bar (A) to the back top cross bar (B) and back bottom cross bar (E) with phillips screw (3) by using Screwdriver.



STEP 4

Carefully place top panel (F) on the assembled frame.

Please make sure the top crossbars are flush with the top crossbars of the legs before placing top panel on assembled frame.




glitzhome®

REQUIRED HARDWARE IN THIS STEP			
NO.	DESCRIPTION	SKETCH	QTY
2	PHILLIP SCREW 5*12mm		6PCS
	PHILLIPS SCREW DRIVER		Not included


STEP 5

Tighten phillips screw (2) using Phillips screwdriver (Not Included).



STEP 6

Carefully place bottom panel (G) into the assembled frame.




glitzhome

REQUIRED HARDWARE IN THIS STEP			
NO.	DESCRIPTION	SKETCH	QTY
2	PHILLIP SCREW 5*12mm		6PCS
	PHILLIPS SCREW DRIVER		Not included

STEP 7

Tighten phillips screw (2) using Phillips screwdriver (Not Included).



STEP 8

