


## Assembly Instruction

## PATIO WICKER SOFA SET



Carefully unpack and identify each component before beginning assembly. Before you begin, please refer to parts list to make sure that you have all parts. Please take care when assembling the unit and always place the parts on a clean, soft surface. If you require assistance with assembly or parts, please call 888-357-7263.

Get social with us and discover more about our products, tips and exclusive discounts!








## **PRE-ASSEMBLY PREPARATION**


## WARNING! DO NOT LET CHILDREN PLAY IN OR AROUND THE UNIT DUE TO THE POSSIBLE RISK OF FINGER ENTRAPMENT

- Please read through this instruction before beginning assembly.
- Two adults assembly is recommended.
- Clear out the space for assembly and lay out all parts base on parts List, extra room will allow you to easily determine if all the pieces are present.
- Save all packing materials until assembly is complete to avoid accidentally discarding smaller parts or hardware.
- Keep small parts and pieces away from children until fully assembly.
- Do not fully tighten the bolts until all have been inserted and hand tightened.
- Please check for any loose screws and tighten them before use.
- If there is any questions, please contact us first, we will quickly solve any doubt for you.




W


Step 1 Attach back panel A2 and A3 to seat panel B1 by using 6 long Bolts (E) and 6 Washers (F). Finally put bolt Caps (G) untl all parts have been connected and bolts are tightened.





Step 2 Connect the two back panels by using 2 Connectors (C), 4 short Bolts (D) and 4 Washers (F). Finally put bolt Caps (G) untl all parts have been connected and bolts are tightened.



Step 3 Atach back panel A1 to seat panel B2 by using 4 long Bolts (E) and 4 Washers (F). Finally put bolt Caps (G) untl all parts have been connected and bolts are tightened. Repeat to assemble two armless sofa.







Step 5 Finally put the cushions on. Coner sofa with two back cushions and armless sofa with one back cushions.

