

## Assembly Instruction

# 2 DRAWER DESK WITH CHARGING



Carefully unpack and identify each component before beginning assembly. Before you begin, please refer to parts list to make sure that you have all parts. Please take care when assembling the unit and always place the parts on a clean, soft surface.


Get social with us and discover more about our products, tips and exclusive discounts!































## PRE-ASSEMBLY PREPARATION



- **CAUTION:** Assembly will require at least 2 adults. DO NOT use power tools. Please inspect all items BEFORE assembly. If for any reason you need to return this item, please kindly return it in it's original packaging.
- **WARNING!**
  1. DO NOT let any sharp objects touch or rub the surface of the product.
  2. When assembling, do not let children play around the working area.
  3. DO NOT tighten all bolts and screws completely until the entire unit has been assembled and set up.
  4. DO NOT USE if this product become damaged, and/or components are broken or missing.
- **CARE AND CLEANING:** DO NOT scratch or chip the finish. DO NOT use abrasive chemicals for cleaning. Clean with mild soap on a soft rag. Rinse and dry thoroughly.
- **MAINTENANCE:** Please periodically check all fittings and re-tighten as necessary.

## Explosive View




PARTS LIST			
BOTTOM CROSS BAR (A)  Qty: 1	BACK TOP CROSS BAR (B)  Qty: 1	REAR X STEEL BAR (C)  Qty: 2	FRONT TOP CROSS BAR (D)  Qty: 1
LEFT LEG (E)  Qty: 1	RIGHT LEG (F)  Qty: 1	DRAWER BOTTOM PANEL (G)  Qty: 2	TOP PANEL (H)  Qty: 1
BOTTOM PANEL (I)  Qty: 1	BACK PANEL (J)  Qty: 1	LEFT PANEL (K)  Qty: 1	RIGHT PANEL (L)  Qty: 1
MIDDLE VERTICAL PANEL (M)  Qty: 1	DRAWER FRONT PANEL (N)  Qty: 2	DRAWER LEFT PANEL (O)  Qty: 2	DRAWER RIGHT PANEL (P)  Qty: 2
DRAWER BACK PANEL (Q)  Qty: 2			
HARDWARE LIST			
CAM (1)  Qty: 17	CAM LOCK (2) Ø15*9mm  Qty: 17	PHILLIPS SCREW (3) M4*37mm  Qty: 17	UMBRELLA HEAD BOLT (4) M4*18mm  Qty: 4


WOOD DOWEL (5) Ø6*30mm  Qty: 20	ALLEN BOLT (6) M6*12mm  Qty: 8	ALLEN BOLT (7) M6*30mm  Qty: 6	ALLEN WRENCH (8) M6*30mm  Qty: 1
DRAWER HANDLE (9)  Qty: 2	PHILLIPS SCREW (10) 4*15mm  Qty: 3	NOT INCLUDED 	

REQUIRED HARDWARE IN THIS STEP			
NO.	DESCRIPTION	SKETCH	QTY
1	CAM		7PCS
5	WOOD DOWEL 6*30MM		6PCS

STEP 1


Insert cam (1) into top panel (H) using Phillips screwdriver (not provided) and full tighten.  
Insert wood dowel (5) into top panel (H).





REQUIRED HARDWARE IN THIS STEP			
NO.	DESCRIPTION	SKETCH	QTY
5	WOOD DOWEL 6*30mm		4PCS

STEP 2


Assemble left side panel (K) and right side panel (L) to back panel (J) using wood dowels (5).






REQUIRED HARDWARE IN THIS STEP			
NO.	DESCRIPTION	SKETCH	QTY
2	CAM LOCK Ø15*9mm		7PCS
	PHILLIPS SCREW DRIVER		Not included

STEP 3


Insert cam lock (2) into holes of side panel (L), side panel (K) and back panel (J). Carefully place assembled side panel (L), side panel (K) and back panel (J) onto top panel (H) and tighten cam locks (2) with phillips screwdriver (not provided ).






REQUIRED HARDWARE IN THIS STEP			
NO.	DESCRIPTION	SKETCH	QTY
1	CAM		2PCS
2	CAM LOCK Ø15*9MM		2PCS
5	WOOD DOWEL 6*30MM		2PCS

#### STEP 4


Insert cam (1) into top panel (H) using phillips screwdriver (not provided ).  
 Insert wood dowel (5) into top panel (H) and insert cam lock (2) into holes of middle panel (M).  
 Carefully place middle panel (M) onto top panel (H).  
 Tighten cam locks (2) with phillips screwdriver (not provided).



REQUIRED HARDWARE IN THIS STEP			
NO.	DESCRIPTION	SKETCH	QTY
3	PHILLIP SCREW 4*37MM		9PCS
5	WOOD DOWEL 6*30MM		8PCS
	PHILLIPS SCREW DRIVER		Not included

STEP 5

Insert wood dowel (5) into side and back panels (L & K) and (J) .  
Carefully place bottom panel (G) onto side and back panels (L & K) and (J) .  
Secure bottom panel in place with phillips screw (3) using phillips screwdriver (not provided).  
Fully tighten all screws.






REQUIRED HARDWARE IN THIS STEP

NO.	DESCRIPTION	SKETCH	QTY
6	ALLEN BOLT M6*12mm		8PCS
8	ALLEN WRENCH		1PC

STEP 6


Assemble front top cross bar (D) and back top cross bar (B) on left leg (E) & right leg (F) with Allen bolts (6) by using Allen wrench (8).





REQUIRED HARDWARE IN THIS STEP			
NO.	DESCRIPTION	SKETCH	QTY
7	ALLEN BOLT M6*30mm		2PCS
8	ALLEN WRENCH		1PC

STEP 7


Assemble back bottom cross bar(A) on left leg (E) and right leg(F) with Allen bolts (7) by using Allen wrench(8).





REQUIRED HARDWARE IN THIS STEP			
NO.	DESCRIPTION	SKETCH	QTY
10	PHILLIP SCREW 4*15mm		3PCS
	PHILLIPS SCREW DRIVER		Not included

STEP 8

Assemble rear X steel bar (C) on back bottom cross bar (A) & back top cross bar (B) with phillips screw (10) by screwdriver (not included).








REQUIRED HARDWARE IN THIS STEP			
NO.	DESCRIPTION	SKETCH	QTY
7	ALLEN BOLT M6*30mm		4PCS
8	ALLEN WRENCH		1PC

STEP 9


Carefully place the assembled metal frame onto the bottom panel (G) and attach with Allen bolts (7) using Allen wrench (8).







REQUIRED HARDWARE IN THIS STEP			
NO.	DESCRIPTION	SKETCH	QTY
3	PHILLIP SCREW 4*37mm		4PCS
	PHILLIPS SCREW DRIVER		Not included

STEP 10

Assemble right side panel of drawer (P) and left side panel of drawer (O) to back panel of drawer (Q) with Phillips screws (3) using Phillips screwdriver (not provided).




### REQUIRED HARDWARE IN THIS STEP



NO.	DESCRIPTION	SKETCH	QTY
1	CAM		4PCS
4	UMBRELLA HEAD BOLT M4*18MM		2PCS
9	HANDLE		1PC
	PHILLIPS SCREW DRIVER		Not included

#### STEP 11

Attach handle (9) to drawer front panel (N) with umbrella head bolts (4) and assemble cam (1) on drawer front panel (N) using phillips screwdriver (not provided).




### REQUIRED HARDWARE IN THIS STEP

NO.	DESCRIPTION	SKETCH	QTY
2	CAM LOCK Ø15*9mm		4PCS
	PHILLIPS SCREW DRIVER		Not included

#### STEP 12


Slide bottom panel of drawer (G) into grooves of assembled side and back panels of drawer. Attach drawer front panel (N) to left and right side panels of drawer using cam lock (2) and phillips screwdriver (not provided). Repeat STEPS 10 though 12 to assemble remaining drawer.



## STEP 13

Align the glides on the drawers with glides in the assembled drawer box.  
Carefully insert the drawer.

Note: If the drawer needs to be removed, depress the plastic levers on the drawer glides and hold to release the drawer.



## STEP 14

