


Assembly Instruction



WARNING: MAXIMUM LOAD NOT EXCEED 45LBS ON SHELVES.

WARNING:

Caution: Assembly will require at least 2 adults, Assemble on soft surface to prevent product finish from any damage. DO NOT use power tools.


CARE AND CLEANING:

DO NOT scratch or chip the finish. DO NOT use abrasive chemicals for cleaning. Clean with mild soap on a soft rag. Rinse and dry thoroughly.













MAINTENANCE:

Check bolts/screws periodically and tighten if necessary. WARNING: Should this product become damaged, and/or components are broken or missing. DO NOT USE.



Explosive View











PARTS LIST


D	1PC	C	1PC	B	1PC
RIGHT UP FRAME		RIGHT BOTTOM FRAME		LEFT UPPER FRAME	
					
A	1PC	J	1PC	K	1PC
LEFT BOTTOM FRAME		BOTTOM CROSS BAR		MIDDIE LONG SHELF CROSS BAR	
					
L	1PC	M	1PC	I	1PC
MIDDIE SHORT SHELF CROSS BAR		TOP LONG SHELF CROSS BAR		TOP SHORT SHELF CROSS BAR	
					
E	1PC	F	1PC	G	1PC
BOTTOM PANEL		MIDDIE LONG SHELF PANEL		MIDDIE SHORT SHELF PANEL	
					

PARTS LIST

H	1PC	N	1PC	
MIDDIE SHORT SHELF PANEL		TOP PANEL		
				

HARDWARE LIST

1	8PCS	M6*10mm	2	30PCS	M6*30mm	3	1 PC	4mm
ALLEN BOLT			ALLEN BOLT			ALLEN BOLT		
								
4	2 PCS	11*13*24mm	5	1 PC	5*200mm	6	1 PC	Ø8.5*30mm
STEEL PLATE			ANTI-TIPPING STRIP			WALL ANCHOR		
								
7	1 PC	4*25mm	8	4PCS	M6*12mm			
SCREW			ALLEN BOLT					
								



NOT INCLUDED

REQUIRED HARDWARE IN THIS STEP

NO.	DESCRIPTION	SKETCH	QTY
1	ALLEN BOLT M6*10mm		8PCS
3	ALLEN WRENCH		1PC


You may need an assistant to finish these steps easily!

Please assemble on a soft flat surface such as carpet or a towel to avoid scratching bookcase and assembly surfaces.

Please **DO NOT** fully tighten all bolts until metal frame assembly is complete.

STEP 1

Assemble right upper frame (D) on right bottom frame (C) with Allen bolts (1) by using Allen wrench(3). Repeat this action for A & B.






REQUIRED HARDWARE IN THIS STEP

NO.	DESCRIPTION	SKETCH	QTY
8	ALLEN BOLT M6*12mm		3PCS
3	ALLEN WRENCH		1PC

STEP 2


Slide the end of right upper frame (D) into the end of left upper frame (B) so the holes align. Secure the frame together with allen bolt (8) using allen wrench (3). Leave the bolt out of the top hole on the outside.





REQUIRED HARDWARE IN THIS STEP			
NO.	DESCRIPTION	SKETCH	QTY
2	ALLEN BOLT M6*30mm		10PCS
3	ALLEN WRENCH		1PC

STEP 3


Attach top short cross bar (I), top long cross bar (M), middle short shelf cross bar (L), middle long shelf cross bar (K) and bottom cross bar (J) with allen bolt (2) using allen wrench (3). DO NOT fully tighten bolts until all cross bars are attached.






REQUIRED HARDWARE IN THIS STEP			
NO.	DESCRIPTION	SKETCH	QTY
2	ALLEN BOLT M6*30mm		20PC
3	ALLEN WRENCH		1PC

STEP 4

Attach top panel (N), middle short shelf panel (G&H), middle long shelf panel (F) and bottom panel (E) to the assembled frame as shown in the diagram with allen bolt (2) using allen wrench (3). Fully tighten all bolts.




REQUIRED HARDWARE IN THIS STEP





NO.	DESCRIPTION	SKETCH	QTY
8	ALLEN BOLT M6*12mm		1PC
4	STEEL PLATE		1PC
3	ALLEN WRENCH		1PC

STEP 5

Attach steel plate (4) to the hole left open on the outside of the top frame with allen bolt (8) using allen wrench (3).



REQUIRED HARDWARE IN THIS STEP

NO.	DESCRIPTION	SKETCH	QTY
4	STEEL PLATE		1 PC
5	ANTI-TIPPING STRIP		1 PC
6	WALL ANCHOR Ø8.5*30mm		1 PC
7	SCREW M4*25mm		1 PC

STEP 6

Place the shelves in the desired location. Mark the spot where the steel plate (4) meets the wall. Remove the shelves. Drill a hole at the marked location and insert the wall anchor (6). Attach the remaining steel plate (4) to wall anchor (6) using phillips screw (7). Return the shelves to the desired position and attach the steel plates (4) with anti-tipping strip (5). Assembly is now complete.

WALL

